


# PANEL SOCKET

**PS001**  
1P RCA jack terminal board  
board  $\phi 25\text{mm}$




**PS008**  
A:6P RCA jack terminal board  
B:8P RCA jack terminal board  
C:10P RCA jack terminal board  
D:12P RCA jack terminal board




**PS015**  
RCA jack PCB type 3P



**PS002**  
1P RCA jack terminal board  
15mm  $\times$  30mm




**PS009**  
A:2P screw terminal board  
B:3P screw terminal board  
C:4P screw terminal board




**PS016**  
RCA jack PCB type 4P



**PS003**  
2P RCA jack terminal board  
20mm  $\times$  52mm




**PS010A**  
RCA jack PCB type 1P



**PS017**  
RCA jack PCB type 5P



**PS004**  
2P RCA jack terminal board  
18mm  $\times$  55mm




**PS011**  
RCA jack PCB type 1P




**PS018**  
RCA jack PCB type 6P



**PS005**  
3P RCA jack terminal board  
22mm  $\times$  60mm



**PS012**  
RCA jack PCB type 1P



**PS019**  
RCA jack PCB type 2P



**PS006**  
4P RCA jack terminal board  
25mm  $\times$  52mm




**PS013**  
RCA jack PCB type 2P



**PS020**  
RCA jack PCB type 3P




**PS007**  
A:4P RCA jack terminal board  
B:5P RCA jack terminal board  
C:6P RCA jack terminal board



**PS014**  
RCA jack PCB type 3P



**PS021**  
RCA jack PCB type 4P



# PANEL SOCKET

## PS022

RCA jack PCB type 6P



## PS029

4P push type speaker terminal board  
20mm × 58mm



## PS036

2P push type speaker terminal board  
57mm × 57mm




## PS023

2P push type speaker terminal board  
21mm × 52mm



## PS030

8P push type speaker terminal board  
30mm × 58mm



## PS037

2P speaker terminal board  
W/plastic binding post  
A:  $\phi$ 75mm  
B:  $\phi$ 105mm



## PS024

2P push type speaker terminal board  
24mm × 53mm



## PS031

2P push type speaker terminal board  
 $\phi$ 55mm



## PS038

2P speaker terminal board  
W/metal binding post  
 $\phi$ 75mm  
 $\phi$ 105mm



## PS025

4P push type speaker terminal board  
19mm × 63mm



## PS032

2P push type speaker terminal board  
 $\phi$ 65mm



## PS039

2P push type speaker terminal board  
65mm × 80mm



## PS026

4P push type speaker terminal board  
24mm × 70mm



## PS033

2P push type speaker terminal board  
 $\phi$ 75mm



## PS040

2P push type speaker terminal board  
60mm × 43mm



## PS027

2P push type speaker terminal board



## PS034

2P push type speaker terminal board  
42mm × 42mm




## PS041

2P push type speaker terminal board  
80mm × 65mm



## PS028

4P push type speaker terminal board  
30mm × 58mm



## PS035

2P push type speaker terminal board  
57mm × 57mm




## PS042

2P push type speaker terminal board  
79mm × 93mm



# PANEL SOCKET

**PS043**  
2P Terminal board  
W/2 × 6.35mm socket



**PS050**  
2P speaker terminal board  
W/plastic binding post  
85mm × 95mm



**PS057**



**PS044**  
8P Speaker Terminal board  
100 × 140mm




**PS051**  
Speaker terminal board w/2\*binding post+2canon females




**PS058**



**PS045**  
2P speaker terminal board  
W/plastic binding post  
79mm × 93mm



**PS052**  
Speaker wall plates with 2binding post



**PS059**




**PS046**  
2P speaker terminal board  
W/metal binding post  
92mm × 78mm




**PS053**  
Speaker wall plates with 4binding post




**PS060**



**PS047**  
4P speaker terminal board  
W/plastic binding post  
95mm × 122mm



**PS054**  
Speaker wall plates with 6binding post




**PS061**



**PS048**  
4P speaker terminal board  
W/metal binding post  
95mm × 122mm




**PS055**  
Speaker wall plates with 8binding post




**PS062**



**PS049**  
2P speaker terminal board  
W/metal binding post  
85mm × 95mm



**PS056**  
Speaker wall plates with 10binding post



**PS063**

